

Installation Guide: Slimline Frame Board



Installation of your slimline board will require two people. It is recommended the board be affixed directly to wall studs for improved sturdiness. If wall studs are not available, Wall-Mates may be used to improve holding strength.

Required Tools



Drill



Tape Measure



Spirit Level



Pencil

Installation Instructions

STEP 1

With a tape measure and pencil, mark the chosen area for installation of your slimline frame board. Use a spirit level to ensure markings are straight.

STEP 2

Position the hanging batten in the chosen area and mark the first screw position on the wall. Remove batten and drill the first wall anchor into position. Loosely fasten the hanging batten into the first screw position. With the aid of a level, straighten the batten and mark the locations of the remaining screw holes. Drill the remaining screw holes and insert the wall anchors. Secure the batten to the wall with the screws.

STEP 3

Lift your board into position on the wall. Ensure the board is sitting securely on the hanging batten and that the frame of the board is flat against the wall. Mark the position of the bottom of the board on the wall.

STEP 4

Remove the board and mark the position of the screw holes for the right angle brackets. Position the brackets so that they will support bottom edge of the board once installed. Drill the bracket holes, insert wall anchors, and secure the brackets to the wall with screws.

STEP 5

Lastly, rehang the board and drill a pilot hole through the bottom of the bracket into the bottom edge of the board. Insert the screws to fix the board to the brackets.

Always ensure wall area is clear of electrical wires before drilling. Whiteboards and Pinboards does not take any responsibility for injuries or breakages in the installation process of your pinboard. Installation is done at your own risk and all safety measures should be taken to avoid injury.

