

Slimline Frame Installation Guide

Installation of your slimline frame board will require TWO people. Where possible install your board to wall studs to deliver improved sturdiness. Where wall studs are not available Wall-Mates may be used to provide extra security when fixing your board to the wall.

What you will need

- Drill
- Tape Measure
- Spirit Level
- Pencil



Installation Instructions

STEP 1

With a tape measure and pencil, mark the chosen area for installation of your slimline frame board. Use a spirit level to make markings straight.

STEP 2

Position the hanging batten in the chosen area and mark the first screw position on the wall. Remove batten and drill the first wall anchor into position.

STEP 3

Loosely fasten the hanging batten into the first screw position. With the aid of a level, straighten the batten and mark the locations of the remaining screw holes. Drill the remaining screw holes and insert the wall anchors. Secure the batten to the wall with the screws.

STEP 5

Lift your board into position on the wall. Ensure the board is sitting securely on the hanging batten and that the frame of the board is flat against the wall.

STEP 6

Once in position fix right angle brackets to the bottom of the frame.

**Ensure wall area is clear of electrical wires before drilling.*

Whiteboards and Pinboards do not take any responsibility for injuries or breakages in the installation process of your whiteboard and pinboard. Installation is done at your own risk and all safety measures should be taken to avoid injury.

