

Standard Frame Installation Guide

Installation of your standard frame board will require TWO people. Where possible install the board to wall studs to deliver improved sturdiness. Where wall studs are not available Wall-Mates may be used to provide extra security when fixing your board to the wall.

What you will need



- Drill
- Tape Measure
- Spirit Level
- Pencil

Installation Instructions

STEP 1

With a tape measure and pencil, mark the chosen area for your standard frame board installation. Use a spirit level to make markings straight. (Measure floor to bottom of board, then to the top of the board followed by the sides).

STEP 2

Place the board on the pencil markings, lining up the bottom edge of the board so that it is positioned on the bottom pencil line.

STEP 3


With board in place, mark the screw positions through the screw holes. Remove board.

STEP 4

Drill holes into the wall to suit the supplied wall plugs. If using Wall-Mates follow manufacturers' instructions.

STEP 5

Insert wall plugs and reposition your board, fixing it into position with screws into the wall plugs. Cover fixings with corner plugs



**Ensure wall area is clear of electrical wires before drilling.*

Whiteboards and Pinboards do not take any responsibility for injuries or breakages in the installation process of your whiteboard or pinboard. Installation is done at your own risk and all safety measures should be taken to avoid injury.